



# WEARWELL®

## PermaTack No. 092 Cleaning Guide



### Materials

#### ✓ Cleaning solution

Recommended Cleaning Agent for Sterile Applications:

IPA or STERIS cleaners. To maintain the functionality of the mat, the ratio of IPA or STERIS to water should not exceed 50%.

Recommended Cleaning Agent for General Applications:

Mix a 25% ammonia/75% water solution, or use Windex or Simple Green All-Purpose.

Other options include non-abrasive, non-oil-based cleaners with pH levels between 4 and 8.



- ✓ **Mop** – with a sponge or cloth head
- ✓ **Squeegee** – optional, but the mat will dry faster if a squeegee is used
- ✓ **Spray bottle**
- ✓ **Clean water**
- ✓ **Bucket**

### Method

1. Mix the cleaning solution in an applicator or spray bottle.
2. Apply an even amount of cleaner on the mat.
3. Wet the surface, but do not create puddles.
4. Mop surface in the direction away from the entrance using short, firm, even strokes. Extra attention may be needed for high traffic and high contamination areas.
5. Thoroughly rinse and ring the mop out with warm, clean water. Use the damp mop to remove any surplus cleaner from the mat and the floor if any cleaner has spilled off the mat.
6. Allow to air dry.

**Warning:** Mats are slippery when wet so remember to squeegee off to expedite drying process.

