

## WOW FINISH

---

### SUPPLIES NEEDED

You will need a broom or a shop vacuum. A general cleaning spray or solution and a mop or towel.

### INSTALLATION INSTRUCTIONS



Using a shop vac or broom, clean the area of dust and debris.



After sweeping, if the area is still dirty or has been exposed to greases and or oils, use a general cleaning solution and wipe down the floor surface with a towel or mop.



If a general cleaning solution was used to clean the area, give the surface some time to dry.



Take WOW! out of the box and carefully place it onto the cleaned, dry surface. Using your hand or foot gently apply pressure on the edges of the mat.

#### Questions?

NORTH AMERICA - Wearwell, LLC  
Phone: 1.800.264.3030  
Wearwell.com

CANADA  
Wearwell.com/ca

MEXICO  
Wearwell.com/mx

EUROPE, UK & IRELAND -  
Wearwell Europe LTD  
Phone: +44.1525.307271  
www.wearwell.com/uk

FRANCE  
www.wearwell.com/fr

GERMANY  
www.wearwell.com/de